

BEFORE USING THIS APPLIANCE FOR THE FIRST TIME, PLEASE READ THE INSTRUCTIONS OF USE AND SAFETY MANUAL CAREFULLY AND KEEP IT FOR FURTHER CONSULTATIONS

Please check immediately that the appliance has not suffered any damage during transportation, if this is the case, kindly inform your distributor. Damage caused by improper handling or use is not covered by the warranty.

SAFETY INSTRUCTIONS AND RISKS

Confirm that the voltage of the electrical network corresponds to those indicated in the technical specifications of the appliance.

The safety of the appliance is guaranteed with an effective ground connection. Do not use multi-socket plugs.

- The appliance and packing items should not be left within reach of children.
- Do not insert any objects into the ventilation vents and keep them 10 cm away from walls or objects that impede proper ventilation of the appliance.
- Store away from explosive materials.
- Avoid all possible sources of ignition (sparks or flames)
- The coolers vibrate and make noise.

The appliance needs periodic maintenance in accordance with these instructions, with proper maintenance the unit is reliable and safe, if it these indications are not followed the risks below might occur:

Electric hazard: Electric shocks can be fatal or cause significant damage, for this reason any unauthorized modification of the electrical system is strictly prohibited. When repairing or cleaning of the equipment it should be done with extreme caution and with the appliance disconnect.

The appliance is equipped with a grounding plug and should only be connected to a grounding socket.

INSTALLATION INSTRUCTIONS

- Unpack the appliance and confirm that it has not suffered any damage during its transportation.
- The appliance must be upright. **Keep the appliance upright at least (2 HOURS) before switching it on.** Once the tank is full of water do not move it.
- The water in the tank should not touch any electric part and the water level should not be above the evaporator.
- The device has digital components that are programmed from the factory. If you need to adjust any of your values, please contact the technical department.
- Before transporting or moving the appliance, the water tank must be emptied, do not wet the electrical parts, melt the ice bank, and clean the coils.

REQUIREMENTS

- For proper operation, the appliance must be between 15°C - 40°C and must not be exposed to humidity or steam.
- Place the appliance on a firm and raised surface to protect it from possible physical damage, and from the accumulation of dirt in the condenser.
- Place it near a **230V/50Hz** socket with grounding socket.
- Place it in a ventilated place, away from any heat source.

Golderos SA C. de la Alcarria, 5, 28823, Coslada, Madrid (SPAIN)

☎: +34 916 75 25 92 | ✉: golderos@golderos.com
www.golderos.com

- **Leave at least 10cm of free space around the appliance, maintaining a minimum distance of 30 cm with other appliances.**
- Keep the area around the grids unobstructed.
- The appliance should be as close as possible to the dispensing taps.

INSTALLATION AND START-UP

The electrical installation must have a grounding socket.

- Connect the product inlet lines from the beer barrel to the coil.
- Connect the beer line of the pipe to the outlet of the coil and connect the circulation pump of the engine to the irrigation of the pipe.
- **Do not plug the appliance yet.**
- Fill the tank with water to the level of the evaporator.
- As the ice bank forms the water level rises and the excess will come out of the overflow. **DO NOT OBSTRUCT THE OVERFLOW.**

Once the appliance is connected, check that the compressor, fan and agitator are working, and the ice-bank formation process begins. Once the ice bank is formed the compressor and fan will stop, but the agitator motor will continue to run.

PRELIMINARY INSPECTION

- Perform a visual inspection to verify that the safety conditions are met.
- Check that the wire is connected correctly, and that the appliance is not on it.
- Check that there are no obstacles to the exit and entry of air from the condenser unit.